


**Instruction Manual for
Leash Plus**



Read through this entire instruction manual BEFORE using your **Leash Plus**.

We're dedicated to bringing you well-designed products that make living fun and easy. We stand behind all our products and warrant this to be free from defects in workmanship and materials for 90 days from the date of purchase.

For service claims or questions, please consult our website ProtocolNY.com.



General Description

1. Water bowl
2. Treat compartment
3. Retractable leash
4. Bag dispenser
5. Clock/date
6. Flashlight

Water bowl:

Removing water bowl



Extending water bowl



Treat compartment:

Loading treats



Retractable leash:

To lock the leash at a desired length, press and then push down the locking button. To release the leash, press and push up the locking button.

Locking leash



Bag dispenser:

Removing bags



Replacing bags



Clock/date:


The clock requires 1 'LR41' battery already included.

Setting the clock:

- To set the month, press the A button twice so that the month displays. Press the B button continually until you reach the desired month.
- To set the day, press the A button again once. Press the B button continually until you reach the desired day.
- To set the hour, press the A button again once. Press the B button continually until you reach the desired hour. Please note this clock is in a 12 hour format so you will scroll through AM and PM hours.
- To set the minute, press the A button again once. Press the B button continually until you reach the desired minute.
- Press the A button once for the normal time display.

Viewing the clock:

- The normal display will show the time in the hour and minute format.
- To view the month and day, press the A or B button once.
- Press the B button again to view the seconds.
- To return to the normal display, press the B button.



Flashlight:

Batteries:

Remove the battery cover and install 3 'AAA' batteries according to indicated polarities.



Turning flashlight on and off:

Push the flashlight button on the back of the handle up to turn on the flashlight and down to turn off the flashlight.

