

Instruction Manual

Rechargeable Swivel Screwdriver



Read through this entire instruction manual BEFORE using your 3.6V **Rechargeable Swivel Screwdriver**.

We're dedicated to bringing you well-designed products that make living fun and easy. We stand behind all our products and warrant this to be free from defects in workmanship and materials for 1 year from the date of purchase.

For service claims or questions please consult our website **ProtocolNY.com**.

Specifications

Screwdriver: Speed: 200 rpm;

Chuck: 1 / 4"=6.35mm (male)

Forward/reverse switch for unscrewing/screwing;

Rechargeable battery: 3.6V

Charger: Input 120V ~ 60HZ

Power: 5VA;

Output: 5V dc, 300mA

Safety instructions

The following recommendations should be strictly complied with before operating the tool:

In order to avoid damage to the equipment and hazard to the user.

1. Wear individual protection equipment if necessary (gloves, shoes, eye protectors, breathing filters, etc.). Do not wear jewelry; protect hair; wear close-fitting clothes.
2. Disconnect the charger when not in use, when you replace a tool, or for equipment maintenance.
3. Work in a room with sufficient lighting.
4. Place and store the tool in a dry place, far from heat or dangerous conditions (best temp. is between 10 to 15). Do not operate the machine close to explosive substances or inflammable material.
5. Use tools in good condition, adapted to the task to be performed, this do-it-yourself equipment should be used as such and not be considered as heavy-duty equipment.

6. Do not work close to people, in particular children if work is hazardous. Keep tools away from children during and after work.
7. Make sure body position is steady as you work.
8. Make sure you do not use the drill or screwdriver on live parts to avoid electric shock. Make sure you locate any electric wire or cable inside the wall before using the tool. (a metal detector may be used for that purpose). Do not touch the chuck, socket or drill bit.
9. Do not try to open or disassemble the tool or the charger. Only a specialist is allowed to service the tool.
10. Should the charger be damaged (case, wires or plug) have it replaced immediately
11. This tool does not require special maintenance. The same applies to the electric part of the tool.
12. Plastic parts should be cleaned only after disconnecting the charger. Use a wet cloth and soft soap. Do not immerse the tool or the charger. The use of solvent, alcohol, gas, etc. is prohibited.

Operation

CAUTION: The **safety instructions** should be read carefully before operating the tool.

Power Supply:

Plug the provided charger into the screwdriver's body. The red indicator lights up as soon as charger is connected.

The indicator shows the battery is charging. It will remain illuminated until the charger is disconnected.

Do not charge the screwdriver for more than 5 hours.

Screwing / Unscrewing:

The screwdriver is equipped with a forward/reverse switch (lever) to change chuck sense of rotation.

1. Clock wise, push the button ▲;
2. Counter-clock wise, push the button ▼

Maintenance

This screwdriver does not require special maintenance. The repair of internal parts of the tool or charger should be left to professionals.